


GAMBAR LOKASI PEMASANGAN UTILITI LAP



Pemasangan Utiliti Air
LAP

Koordinat Awal : 4.889221, 100.722810

Koordinat Damar : 4.890359103700913, 100.72241272849216

Koordinat Pulai : 4.891210793406122, 100.72209836407416

Koordinat Akhir : 4.891838393931014, 100.72181849103421

Kaedah Korekan : Korekan Jalan Berturap dan tanah

GAMBAR LOKASI
LOKASI MULA



Pemasangan Utiliti Air
LAP

LOKASI DAMAR



Pemasangan Utiliti Air
LAP

LOKASI PULAI



LOKASI AKHIR



